

Frankfurt FIR Airports

Note: Not for real navigation!

Effective: 01.03.2004

Rammstein (ETAR)

ICAO-code: ETAR

IATA-code:

Position: N49 26.3 E007 36.1

Altitude: 782 ft

Magnetic Variation: 00°

Transition Altitude: 5000 ft

Transition Level: by ATC

Summer LT: UTC(Z) plus 2 hours

Winter LT: UTC(Z) plus 1 hour

NAVAIDS:

ILS DME 27 110.5 / 266° (IRMS)

ILS DME 09 111.5 / 086° (IRST)

TACAN 27 CH 81 RMS

TACAN 09 CH 81 RMS

RMS CH 81

Communication:

Station	Login	Frequenz
Ground	ETAR_V_GND	121.77
Tower	ETAR_V_TWR	123.55
Langen Radar	EDFF_V_CTR	127.50

HOLDINGS :

FRANK Track 268° RT MSA 5000

MAPIG Track 094° RT MSA 5000

IAF RWY 27

IAF RWY 09

Standard Instrument Departure Routes :

RWY 09:

BOLKI 1

On 087° track to RMS 3 DME, turn LEFT, intercept RMS R-061 (non-TACAN equipped aircraft 055° track) to BOLKI.

5000 ft

1. Expect further clearance prior to BOLKI or passing 4000`.

2. SID not plannable without transition!

Transitions:

1E: Proceed via airways Q 762, Z 12 to NKR.

1N: Proceed via airway Q 762 to OLIVI.

1S: Proceed via airway Q 762 to BADLI.

1W: Proceed via airways Q 762, W 718 to SBN.

RWY 27:

TOLEY 1

On 267° track to RMS 2 DME, turn RIGHT, intercept RMS R-283 (non-TACAN equipped aircraft 283° track) to TOLEY.

5000 ft

1. Expect further clearance prior to TOLEY or passing 3400`.

2. SID not plannable without transition!

Transitions:

1E: Proceed via airways Q 76, Z 729, W 718 to NKR.

1N: Proceed via airway Q 760 to IDARO.

1S: Proceed via airway Q 760, Z 729 to BADLI.

1W: Proceed via airways Q 762 to SBN.